

LOAN TRAILER

PURPOSE OF THIS DOCUMENT

This document is intended to help the borrower to fold the trailer for storage or for putting into a car boot. Please see the Ebike Loan instructions for info on how to use the trailer.



The trailer is attached to the bike by:

1. plugging in the spring rod on the trailer to the black adapter on the bike.
2. Pushing the pin through the hole in the spring rod.
3. Pushing the spring clip over the end of the pin.

COLLAPSING THE TRAILER FOR STORAGE OR CAR TRANSPORT



The trailer is easily collapsed by:

1. Taking off the cover via the Velcro straps.





2. Pressing the red button on the 45 degree side rods.



2. Slide the rods outwards to release them.



3. And then tuck them between the seat back and the vertical rod.



4. The vertical rods can then be pushed forwards to fold the top flat. You can stop here if you wish.



5. To further reduce the size, you can pull out the pin underneath the front of the trailer



6. Fold the towing arm underneath the trailer.



-----END OF DOCUMENT -----